

Figure 4-10 List of Barcode Type






Figure 4-11 Character Options

4.7.2 Curve text function

EzCad2 support curve text function, if the user draw text near enough from the curve, the text will

arrange along the curve. When current text is curve text, click  fig 4-12 will pop-up:

 Normal mean text will be parallel with the curve, as fig 4-13.





Fig 4-13 normal arrange

 Project means text will be vertical with the curve, as fig 4-14.






Fig 4-14 vertical arrange

 Base means the base line of the text is superposition with the curve, as fig 4-13.

 Top means the top of the text is superposition with the curve, as fig4-15.





Fig 4-15 top arrange

 Bottom means bottom of the text is superposition with curve, as fig 4-16.




Fig 4-12 curve text




Fig 4-16 bottom arrange



means middle of the text is superposition with curve, as fig 4-17.



Fig 4-17 middle arrange



means text stay on the curve freely along with the curve, the

position of the text is up to

Base length	0
Offset length	0

 as fig 4-18.




Fig 4-18 freely arrange



put text on the other side of the curve, after this function, fig 4-13 will like fig 4-19.





Fig 4-19 put text on the other side of the curve



when put text on circle, we use this function.

Base angle: means the angle of the base line of the text.

Angle range limit: when we click it, no matter how many characters we input, system will compress all the characters in the limit angle, as fig 4-20.




Fig 4-20 limit the angle as 45